



* For 5V , please connects with wires directly.
 For 12V , please series connects with the resistance of 1K($\geq 1/4$ W).
 For 24V , please series connects with the resistance of 2K($\geq 1/2$ W).

* The choice of the output power for power supply needs to be made according to the actual condition.
 Output Power of 350W is just for your reference.

NOTE: when you don't use enbl ports, no need to connect enbl ports

旧底图号

底图总号

日期 签名

格式 (1)

				BREAK OUT BOARD+HBS57*3		CHANGZHOU LONGS MOTOR CO., LTD WWW.LONGS-MOTOR.COM		
更改标记	更改单号	签名	日期			等级标记	重量	比例
设计	Leeham	2018.5.4		1	共	张		
审核								
工艺								
更新								
标准化								
批准								